

American DJ® User Instructions

Charisma II™



CAUTION! Read instructions before installing or plugging unit in.

SPECIFICATIONS: MODEL - Charisma II™

Weight:	16 lbs.
Size:	21.25"H x 9.5"W x 4.75)L
Lamp:	ZB-EXY 250W 82V
Fuse:	5A AGC
Power Supply:	120V
Working Position:	Any Safe position
Duty Cycle:	10 min. on 10 min. off
Gobos:	1Fixed Gobo/1 Rotating Gobo Per Side
Cooling:	Fan cooled

HALOGEN LAMP WARNING!

This fixture is fitted with a halogen lamp which is highly susceptible to damage if improperly handled. Never touch lamp with bare fingers as the oil from your hands will shorten lamp life. Also, never move fixture until lamp has had ample time to cool. Remember, lamps are not covered under warranty conditions.

Operating Instructions:

This unit has been lamped and tested for quality control at American DJ. This unit is ready to be hung or set on a flat surface. After plugging the unit in the outer dichroic mirror dishes will react to sound via the internal microphone. The internal gobos will overlap creating a unique tunnel effect that expands and contracts. Adjust the sensitivity knob on the top of the unit for sound sensitivity. Focus the front lenses so the beam patterns are in focus for the height the fixture is mounted. Be sure not to obstruct the cooling vents and keep this fixture in a well ventilated area. For optimal beam enhancement use a fog machine.

Caution! Never open this or any electrical unit when in use. Always disconnect main power before serving or replacing lamp. Remember always replace same lamp and fuses as original unless otherwise specified by technician. For best effect, periodically clean the front focus lens with a glass cleaner.

Lamp replacement: *Always disconnect main power before attempting lamp replacement. Do not attempt lamp replacement while fixture is hot.* Open top lid cover by removing the thumb screw on the top of the unit and pull lamp from socket. Remove and replace lamp.

The *American DJ* Charisma II™ comes with a 90 day limited warranty. We recommend filling out the warranty registration card that came with your fixture to validate your warranty. For service contact *American DJ*™.